



155 Knickerbocker Ave
Bohemia
NY, 11716

Ph: 631 750 6440
Fax: 631 206 9220
Email: sales@queuesolutions.com

Floor Socket Installation General Guidelines

NOTE: These instructions are intended as general guidelines only. Professional installation is recommended. Contractors must use their own judgement on the best method of installation depending on floor type and any other relevant circumstances.

Socket Installation

- 1) Mark floor with the desired post configuration, ensure the post spacing is at least 6" less than the belt length (e.g. 10'6" for an 11' belt)
- 2) Core drill holes approximately 4" dia x 6" deep.
Tip: Mark the edges of the drill core as the center will not be visible when aligning the drill head.
- 3) Break out the core and chisel out the base if domed.
- 4) Vacuum out the excess debris and dust from the drilled core.
- 5) Pour non-shrinking adhesive grout to approximately one third the depth of the core.
- 6) Insert the post into the socket.
- 7) Insert the socket into the drill core.
- 8) Check the level of the post, adjusting with suitable wedges under the base plate.
- 9) Leave grout to cure for the recommended length of time.

Post Fitting and Removal

- 1) With the socket cap removed, position the base of the post into the recess of the floor socket and push down.
- 2) When fully fitted, the base of the post will sit flush with the top of the floor socket. To remove the post, pull directly upwards until removed. Replace socket cap to keep recess free of detritus.