



155 Knickerbocker Ave
Bohemia
NY, 11716

Ph: 631 750 6440
Fax: 631 206 9220
Email: sales@queuesolutions.com

Mini Floor Socket Installation General Guidelines

NOTE: These instructions are intended as general guidelines only. Contractors must use their own judgment on the best method of installation depending on floor type and any other relevant circumstances.

Socket Installation

1. Lay out socket locations
2. Drill 15/16" hole approximately 2" deep.
3. Clean and inject epoxy into hole.
4. Insert anchor flush with floor and allow epoxy to cure.