

Oval Sign Assembly Instructions



1. Using a suitable allen key back out the set screws to leave the slot in the sign holder clear



2. Insert the sign into the slot ensuring the holes in the sign are aligned with the set screws



3. Tighten the set screws making sure they are wound all the way in so they pass through the holes in the sign

