

Wall Mounted Unit Installation

1 Place the wall mounted unit in the position required and using a pencil mark the position of the four screw holes.



2 Using a 17/64 drill bit, drill four holes in the positions marked.

3 Insert a wall anchor (supplied) in each hole making sure the plug is flush with the wall surface. Note: may require a light tap with a hammer.



4 Place the wall unit over the screw holes and using the screws supplied screw the unit to the wall.

5 Attach the top and bottom caps to the wall unit

6 Clip the Wall Receiver to the Belt End and extend the belt to the opposite wall and using a pencil mark the required position for Wall Receiver's screw holes

7 Using a 17/64 drill bit, drill two holes in the positions marked

8 Insert a wall anchor in each hole making sure the anchor is flush with the wall surface Note: may require a light tap with a hammer.

9 Place the Wall Receiver over the screw holes and using the screws supplied screw the unit to the wall.

WARNING: Before drilling into a wall always ensure the area is clear of any electrical wiring or plumbing pipes