

335 Model Belt Cassette Replacement Instructions.

4.5" Diameter Cassette



Replacement Cassette



Phillips Screwdriver (not supplied)

1

Remove the four screws securing the cap to the cassette housing.



2

Remove the cap from the top of the housing.



3

Slide the cassette out of the housing.



4

Fit the replacement cassette into the housing.



5

Replace the cap on to the cassette housing.



6

Tighten the four screws securing the cap to the housing.

